

## Wall Fixing the Bracket

1. Mark the top hole position for each bracket by 2.95cm above the pole centre line previously marked. (fig.3)
2. Use the bracket as a template to mark the second hole position onto the wall. (fig.4)
3. Drill holes and fit the correct plugs if fixing on masonry wall.
4. Fix the bracket using the correct screws. (fig.5)
5. The bracket can be adjusted in projection by unscrewing the inner screw. Once in the desired position, lock in place by tightening the inner screw. (fig.6)

