

Streamline

Fixing Instructions

120cm - 210cm 1 piece fixing instructions

Before you begin we recommend -

The end of the track overhangs the window frame by about 10cm/4".

the track will be level.

The supports are level, equally spaced and past the edge of the window.

There is a gap for the end caps after the last support.

- a) Wall fix

or

b) Top fix
- 6mm

12.5cm/5"

2.5cm/1"
- When hanging the supports make sure they are level.
-
-

Bending into a bay

200mm/8" WALL

200mm/8" WALL

90°

Generate a smooth bend by positioning the supports as shown.

Cutting the track

Trim the track if required. Please remove the end cap prior to cutting. Trim from one end. Replace and secure end cap.

240cm - 420cm 2 piece fixing instructions

Before you begin we recommend -

The end of the track overhangs the window frame by about 10cm/4".

the track will be level.

The supports are level, equally spaced and past the edge of the window.

There is a gap for the end caps after the last support.

There is no support placed at the centre where the join will be.

We recommend two people hang this track

- a) Wall fix

or

b) Top fix
- 240-420cm

6mm

12.5cm/5"

2.5cm/1"

When hanging the supports make sure they are level. Do not place a support at the centre where the joining connector will be.
-
- Connector 240-420cm**
-
- Bending into a bay**

200mm/8" WALL

200mm/8" WALL

90°

Generate a smooth bend by positioning the supports as shown.
- Cutting the track**

Trim the track if required. Please remove the end caps prior to cutting. Trim an equal amount from each end. Replace and secure end caps.