

## Fixing the finial

1. If the collar is already installed on the pole, unscrew the grub screw and remove the collar. We do not recommend to install the finial while the collar is installed as it could scratch the pole. (fig.18)
2. Screw the finial on the cup end of the collar. Please note that different design are available through the range. (fig.19)
3. Push the finial onto the end of the pole. (fig.20)
4. Tighten the grub screw on the collar.

